

Kit zavorre C0

ADAM - EDEN - EVE - PLAY

ISTRUZIONI PER IL MONTAGGIO
ASSEMBLY INSTRUCTIONS



*Si prega di conservare le seguenti istruzioni.
Please keep the following instructions.*



de Majo ILLUMINAZIONE S.r.l.
30035 Mirano (VE) Italy - Via Galilei, 34 (z.ind.)
Ufficio Commerciale Italia tel. 041 57 29 653
e-mail: p.brunello@demajomurano.com
Export Departement tel.+39 041 57 29 654
e-mail: export@demajomurano.com
Telefax +39 041 57 02 533
www.demajoilluminazione.com

Kit zavorre

ISTRUZIONI DI MONTAGGIO

NOTA:

Prima di eseguire ogni operazione assicurarsi di aver disinserto l'alimentazione di rete.

1. Sguainare di 2 cm i cavi d'acciaio "A" ed inserirli nei gripper "B" posti sulle zavorre metalliche "C".

- Fissare i due cavi elettrici "D" con i finali isolatori in plastica "E" avvitando i grani "F".

Weights kit

ASSEMBLY INSTRUCTIONS

WARNING:

Before proceeding with the assembly operation, disconnect the electrical supply at the fuseboard.

1. Remove sheath from steel cables "A" for about 2 cm. Then insert cables into gripper "B" placed on weights "C".

- Fix the two electrical cables "D" to the two plastic part "E" by tightening screws "F".

Fig.1

